


Silica ridge waveguides design

April 06th 2023

Zoom Meeting


Participants: S. Amann, L. Deniel, L. Wu, B. Xu, K. J. Vahala, N. Picqué, T. W. Hänsch

SiO₂ ridge rectangular waveguides




SiO2 ridge rectangular waveguides

TM mode





TE mode





Estimation of the fission length for SC generation (rectangular wg)

TE modes in 2 μm thick rectangular waveguides, using our 1.55 μm , 70 fs pump, for different average pump power:



Estimation of the fission length for SC generation (triangular wg)

TM modes in triangular waveguides, using a frequency doubled pump (@785 nm, 100 fs), for different average pump power:



Conclusion

In conclusion, the interesting waveguides have the following dimensions:

Rectangular waveguides:

Under-layer: 450 nm

Height: 2000 nm (**under layer not included**)

Widths: from 1500 to 5000 nm

Length: 1.5 cm

Triangular waveguides:

Under-layer: 450 nm

Widths: from 1200 to 2500 nm

Length: 1.5 cm

Open question : how many waveguides / what width step ?